

Installing The Lil'Chromies

1. Firmly grasp the stock door lock knobs and twist them counter-clockwise to remove them from the threaded door lock post. You may need a pair of pliers to remove the stock door lock knobs.
2. Clean the threaded door lock post thoroughly with a paper towel and rubbing alcohol or fingernail polish remover.
3. Repeat steps 1 and 2 on the other side of the car.
4. Read instructions and warning on adhesive pouch.
5. Carefully trim a small amount of the bottom of the adhesive pouch off so that just the "tip" of the outlet channel is cut through (cut between the words "tear" and "here" to create as small a tip as possible).
6. Squeeze the pouch to dispense 4 drops into the hole of your Lil'Chromies.
7. Carefully and quickly turn over the Lil'Chromies and slide onto the threaded door lock post. Move quickly so the adhesive does not drip out and onto your door panel.
8. Twist the Lil'Chromies counter clockwise while pressing down until the Lil'Chromies are bottomed on the threaded door lock post.
9. The adhesive will tack up in about 1 hour and reach full strength in 24 hours. Please do not disturb the Lil'Chromies while the adhesive is curing.

NOTE: In the event your door needs to be serviced, our Lil'Chromies are designed with this in mind, simply pull door off over the Chromies.